



Troubleshooting

If you are having trouble with the accuracy of your CatchCounter please go thru this list of items that may contribute to the problem.

- Be sure the unit is clean, check the underside where the counting flap pivots, for fish scale buildup and that the flap pivots with no drag.
- Make sure the arm on the counter is secure and has not moved. The arm should be at a 45 degree angle off the base.
 - Check both springs, they should not be stretched.
- If adjustment is needed, disconnect the upper spring. Set arm so it pulls the flap up as far as it can go. Tighten the arm on the counter shaft, it should be at roughly a 45 degree angle to the base. Loosen the top spring adjuster, and connect the top spring to the counting arm. When adjusting the top spring put enough tension on it to pull the counting arm all the way back to its stop at the end of each count. This resets the counter for the next fish. Test it with your hand and re-adjust if necessary.

Do and Don't

- Do keep your CatchCounter clean inside and out.
- Don't abuse the unit. Just drop a single fish in at a time.
- Don't forcefully dunk or throw fish in, double-counts can happen.
- Do keep small fish in your hand while putting it thru the flap to trigger the count, then release.
 - Do watch the counter every time you drop a fish in.